

STEP. 08

```

*****
*
*          Fi l e n a m e          :  STEP. 08          *
*
*          D a t a   V e r s i o n   :  3. 1          *
*
*          P r o d u c e r          :  [REDACTED]        *
*
*          C h e c k e r            :  [REDACTED]        *
*
*          D a t e                  :  25/05/2016       *
*
*****

```

/*

Stepping Table file for Signal box Code 08

Item	Berth	Berth Type Characteristics	OCU	SYST	TOTX RXAD	S	[Tri gger], Condi ti ons
------	-------	-------------------------------	-----	------	--------------	---	--------------------------

*/

```

0001: 4001   N
0002:                                     4019 N
[TRAG], R4001BM. (S4001+LS4001(RR)I)
0003:                                     4022 N
[TRAG], R4001AS. (S4001+LS4001(RR)I)
0004:                                     4981 N [S4981], 4001. -PLT1. -4981
0005:                                     4981 N [LS4981(RR)I], 4001. -PLT1. -4981
0006:                                     COUT N
[TRAG], R4001CS. (S4001+LS4001(RR)I)
0007:                                     COUT N [-TRAC], -TRAD. -TRAE. 4001
0008:                                     COUT N [-TRAE], -TRAC. -TRAD. 4001
0009:                                     PLT1 N [R4014GSP], 4001. -PLT1
0010:                                     PLT1 N [R4016FC], 4001. -PLT1
0011:                                     PLT1 N [R4020FC], 4001. -PLT1
0012:                                     PLT1 N [R4022FC], 4001. -PLT1
0013:                                     PLT1 N [-PLT1], R4014GSP. 4001
0014:                                     PLT1 N [-PLT1], R4016FC. 4001
0015:                                     PLT1 N [-PLT1], R4020FC. 4001
0016:                                     PLT1 N [-PLT1], R4022FC. 4001
0017:                                     AEDN C R4001BM
0018: 4002   N
0019:                                     4019 N
[TRAG], R4002BM. (S4002+LS4002(RR)I)
0020:                                     4022 N
[TRAG], R4002AS. (S4002+LS4002(RR)I)
0021:                                     COUT N
[TRAG], R4002CS. (S4002+LS4002(RR)I)
0022:                                     COUT N [-TRAH], 4002
0023:                                     R002 N [R4014FSP], 4002. -R002
0024:                                     R002 N [R4016EC], 4002. -R002
0025:                                     R002 N [R4020EC], 4002. -R002
0026:                                     R002 N [R4022EC], 4002. -R002
0027:                                     AEDN C R4002BM
0028: 4003   N
0029:                                     4019 N
[TNCW], R4003BM. (S4003+LS4003(RR)I)
0030:                                     4022 N
[TNCW], R4003AS. (S4003+LS4003(RR)I)
0031:                                     4983 N [S4983], 4003. -PLT3. -4983
0032:                                     4983 N [LS4983(RR)I], 4003. -PLT3. -4983
0033:                                     COUT N
[TNCW], R4003CS. (S4003+LS4003(RR)I)
0034:                                     COUT N [-TNCT], -TNCU. -TNCV. 4003
0035:                                     COUT N [-TNCV], -TNCT. -TNCU. 4003
0036:                                     PLT3 N [R4014ESP], 4003. -PLT3

```

STEP. 08

0037:	PLT3 N [R4016DC], 4003. -PLT3
0038:	PLT3 N [R4020DC], 4003. -PLT3
0039:	PLT3 N [R4022DC], 4003. -PLT3
0040:	PLT3 N [-PLT3], R4014ESP. 4003
0041:	PLT3 N [-PLT3], R4016DC. 4003
0042:	PLT3 N [-PLT3], R4020DC. 4003
0043:	PLT3 N [-PLT3], R4022DC. 4003
0044:	AEDN C R4003BM
0045: 4004 N	
0046:	4019 N
[TNDY], R4004BM. (S4004+LS4004(RR)I)	
0047:	4022 N
[TNDY], R4004AS. (S4004+LS4004(RR)I)	
0048:	4984 N [R4012DSP], 4004. -4984
0049:	4984 N [R4014DSP], 4004. -4984
0050:	4984 N [R4016CC], 4004. -4984
0051:	4984 N [R4020CC], 4004. -4984
0052:	4984 N [R4022CC], 4004. -4984
0053:	4984 N [S4984], 4004. -4984
0054:	4984 N [LS4984(RR)I], 4004. -4984
0055:	COUT N
[TNDY], R4004DS. (S4004+LS4004(RR)I)	
0056:	COUT N
[TNDY], R4004CS. (S4004+LS4004(RR)I)	
0057:	COUT N [-TNDW], -TNDX. 4004
0058:	COUT N [-TNDX], -TNDW. 4004
0059:	AEDN C R4004BM
0060: 4006 N	
0061:	4019 N
[TPWB], R4006BM. (S4006+LS4006(RR)I)	
0062:	4022 N
[TPWB], R4006AS. (S4006+LS4006(RR)I)	
0063:	4986 N [S4986], 4006. -PLT6. -4986
0064:	4986 N [LS4986(RR)I], 4006. -PLT6. -4986
0065:	COUT N
[TPWB], R4006CS. (S4006+LS4006(RR)I)	
0066:	COUT N
[TPWB], R4006DS. (S4006+LS4006(RR)I)	
0067:	COUT N [-TPWD], -TPWE. -TPWF. 4006
0068:	COUT N [-TPWF], -TPWD. -TPWE. 4006
0069:	PLT6 N [R4012CSP], 4006. -PLT6
0070:	PLT6 N [R4014CSP], 4006. -PLT6
0071:	PLT6 N [R4016BC], 4006. -PLT6
0072:	PLT6 N [R4020BC], 4006. -PLT6
0073:	PLT6 N [R4022BC], 4006. -PLT6
0074:	PLT6 N [-PLT6], R4012CSP. 4006
0075:	PLT6 N [-PLT6], R4014CSP. 4006
0076:	PLT6 N [-PLT6], R4016BC. 4006
0077:	PLT6 N [-PLT6], R4020BC. 4006
0078:	PLT6 N [-PLT6], R4022BC. 4006
0079:	AEDN C R4006BM
0080: 4007 N	
0081:	4019 N
[TPVD], R4007BM. (S4007+LS4007(RR)I)	
0082:	4022 N
[TPVD], R4007AS. (S4007+LS4007(RR)I)	
0083:	4987 N [S4987], 4007. -PLT7. -4987
0084:	4987 N [LS4987(RR)I], 4007. -PLT7. -4987
0085:	COUT N
[TPVD], R4007CS. (S4007+LS4007(RR)I)	
0086:	COUT N
[TPVD], R4007DS. (S4007+LS4007(RR)I)	
0087:	COUT N [-TPVE], -TPVF. -TPVG. 4007
0088:	COUT N [-TPVG], -TPVE. -TPVF. 4007
0089:	PLT7 N [R4012BSP], 4007. -PLT7
0090:	PLT7 N [R4014BSP], 4007. -PLT7
0091:	PLT7 N [R4016AC], 4007. -PLT7
0092:	PLT7 N [R4020AC], 4007. -PLT7

STEP. 08

0093:	PLT7 N [R4022AC], 4007. -PLT7
0094:	PLT7 N [-PLT7], R4012BSP. 4007
0095:	PLT7 N [-PLT7], R4014BSP. 4007
0096:	PLT7 N [-PLT7], R4016AC. 4007
0097:	PLT7 N [-PLT7], R4020AC. 4007
0098:	PLT7 N [-PLT7], R4022AC. 4007
0099:	AEDN C R4007BM
0100: 4012 N	
0101:	COUT N [TRBF], R4012AS. S4012
0102:	4987 N [TRBF], R4012BSP. S4012
0103:	4007 N [TRBF], R4012BSP. S4012
0104:	4986 N [TRBF], R4012CSNP. S4012
0105:	4006 N [TRBF], R4012CSP. S4012
0106:	4984 N [TRBF], R4012DSNP. S4012
0107:	4004 N [TRBF], R4012DSP. S4012
0108: 4014 N	
0109:	COUT N [TRBG], R4014AS. S4014
0110:	4987 N [TRBG], R4014BSP. S4014
0111:	4007 N [TRBG], R4014BSP. S4014
0112:	4986 N [TRBG], R4014CSNP. S4014
0113:	4006 N [TRBG], R4014CSP. S4014
0114:	4984 N [TRBG], R4014DSNP. S4014
0115:	4004 N [TRBG], R4014DSP. S4014
0116:	4983 N [TRBG], R4014ESNP. S4014
0117:	4003 N [TRBG], R4014ESP. S4014
0118:	4002 N
[TRBG], (R4014FSNP+R4014FSP). S4014	
0119:	4981 N [TRBG], R4014GSNP. S4014
0120:	4001 N [TRBG], R4014GSP. S4014
0121: 4016 N	
0122:	4987 N
[TPXU], R4016AM. (S4016+LS4016(RR)I)	
0123:	4007 N
[TPXU], R4016AC. (S4016+LS4016(RR)I)	
0124:	4986 N
[TPXU], R4016BM. (S4016+LS4016(RR)I)	
0125:	4006 N
[TPXU], R4016BC. (S4016+LS4016(RR)I)	
0126:	4984 N
[TPXU], R4016CM. (S4016+LS4016(RR)I)	
0127:	4004 N
[TPXU], R4016CC. (S4016+LS4016(RR)I)	
0128:	4983 N
[TPXU], R4016DM. (S4016+LS4016(RR)I)	
0129:	4003 N
[TPXU], R4016DC. (S4016+LS4016(RR)I)	
0130:	4002 N
[TPXU], R4016EM. (S4016+LS4016(RR)I)	
0131:	4002 N
[TPXU], R4016EC. (S4016+LS4016(RR)I)	
0132:	4981 N
[TPXU], R4016FM. (S4016+LS4016(RR)I)	
0133:	4001 N
[TPXU], R4016FC. (S4016+LS4016(RR)I)	
0134:	UNLE H
0135: 4019 D[4020]	
0136:	4020 N [S4020], 4019
0137:	4020 N [LS4020(RR)I], 4019
0138:	4027 N [TNEJ], TNEF. S4019
0139:	DNLN H
0140: 4020 D[4019]	
0141:	4987 N
[TNED], R4020AM. (S4020+LS4020(RR)I)	
0142:	4007 N
[TNED], R4020AC. (S4020+LS4020(RR)I)	
0143:	4986 N
[TNED], R4020BM. (S4020+LS4020(RR)I)	
0144:	4006 N

STEP. 08

[TNED], R4020BC. (S4020+LS4020(RR)I)	
0145:	4984 N
[TNED], R4020CM. (S4020+LS4020(RR)I)	
0146:	4004 N
[TNED], R4020CC. (S4020+LS4020(RR)I)	
0147:	4983 N
[TNED], R4020DM. (S4020+LS4020(RR)I)	
0148:	4003 N
[TNED], R4020DC. (S4020+LS4020(RR)I)	
0149:	4002 N
[TNED], R4020EM. (S4020+LS4020(RR)I)	
0150:	4002 N
[TNED], R4020EC. (S4020+LS4020(RR)I)	
0151:	4981 N
[TNED], R4020FM. (S4020+LS4020(RR)I)	
0152:	4001 N
[TNED], R4020FC. (S4020+LS4020(RR)I)	
0153: 4022 N	
0154:	4987 N
[TRAL], R4022AM. (S4022+LS4022(RR)I)	
0155:	4007 N
[TRAL], R4022AC. (S4022+LS4022(RR)I)	
0156:	4986 N
[TRAL], R4022BM. (S4022+LS4022(RR)I)	
0157:	4006 N
[TRAL], R4022BC. (S4022+LS4022(RR)I)	
0158:	4984 N
[TRAL], R4022CM. (S4022+LS4022(RR)I)	
0159:	4004 N
[TRAL], R4022CC. (S4022+LS4022(RR)I)	
0160:	4983 N
[TRAL], R4022DM. (S4022+LS4022(RR)I)	
0161:	4003 N
[TRAL], R4022DC. (S4022+LS4022(RR)I)	
0162:	4002 N
[TRAL], R4022EM. (S4022+LS4022(RR)I)	
0163:	4002 N
[TRAL], R4022EC. (S4022+LS4022(RR)I)	
0164:	4981 N
[TRAL], R4022FM. (S4022+LS4022(RR)I)	
0165:	4001 N
[TRAL], R4022FC. (S4022+LS4022(RR)I)	
0166:	4B22 N [R4001AS], -4B22. 4022
0167:	4B22 N [R4002AS], -4B22. 4022
0168:	4B22 N [R4003AS], -4B22. 4022
0169:	4B22 N [R4004AS], -4B22. 4022
0170:	4B22 N [R4006AS], -4B22. 4022
0171:	4B22 N [R4007AS], -4B22. 4022
0172: 4B22 N	
0173:	4022 N [S4022], 4B22. -4022
0174:	4022 N [LS4022(RR)I], 4B22. -4022
0175: 4026 N	
0176:	4016 N [TPXR], TPXK. S4026
0177: 4027 N	
0178:	4029 N [TNEM], S4027+LS4027(RR)I
0179: 4028 N	
0180:	4026 N [TPXG], S4028+LS4028(RR)I
0181: 4029 N	
0182:	4031 N [TNER], TNEP. S4029
0183: 4030 N	
0184:	4028 N [TPXF], TPXD. S4030
0185:	4190 N [S4190], 4030. -4190
0186: 4031 N	
0187:	4035 N
[TNET], R4031AM. (S4031+LS4031(RR)I)	
0188:	4188 N
[TNET], R4031BM. (S4031+LS4031(RR)I)	
0189: 4034 N	

0190:
 0191:
 0192: 4035 N
 0193:
 0194: 4036 N
 0195:
 0196: 4037 N
 0197:
 0198: 4042 N
 0199:
 0200: 4043 N
 0201:
 0202: 4050 N
 0203:
 [TYLN], R4050AM. (S4050+LS4050(RR)I)
 0204: 4051 N
 0205:
 [TSJB], R4051AM. (S4051+LS4051(RR)I)
 0206:
 0207: D451 N, V
 0208:
 0209: DNLM N, V
 0210:
 0211: 4062 N
 0212:
 [TYLE], R4062AM. (S4062+LS4062(RR)I)
 0213:
 0214: U462 N, V
 0215:
 0216: UPLM N, V
 0217:
 0218: 4065 N
 0219:
 [TSJG], R4065AM. (S4065+LS4065(RR)I)
 0220: 4071 N
 0221:
 [TSJM], R4071AM. (S4071+LS4071(RR)I)
 0222: 4072 N
 0223:
 [TYKW], R4072AM. (S4072+LS4072(RR)I)
 0224: 4074 N
 0225:
 [TYKP], R4074AM. (S4074+LS4074(RR)I)
 0226: 4073 N
 0227:
 [TSJU], R4073AM. (S4073+LS4073(RR)I)
 0228:
 R4073AM. R4079AM. R4089AM. -4079. -4089
 0229: 4079 N
 0230:
 [TSJZ], R4079AM. (S4079+LS4079(RR)I)
 0231:
 0232: 4082 N
 0233:
 [TYKJ], R4082AM. (S4082+LS4082(RR)I)
 0234: 4089 N
 0235:
 [TSKC], R4089AM. (S4089+LS4089(RR)I)
 0236:
 0237: 4091 D[4092]
 0238: T
 0239:
 [TYKB], R4091AM. (S4091+LS4091(RR)I)
 0240:
 0241: 4092 D[4091]
 0242: T
 0243:
 [TYKD], R4092AM. (S4092+LS4092(RR)I)

STEP. 08

4030 N [TYHZ], S4034+LS4034(RR)I
 ANUN C S4034+LS4034(RR)I
 4037 N [TSHC], S4035
 4034 N [TYHT], S4036
 4043 N [TSHJ], S4037
 4036 N [TYHC], S4042
 4051 N [TSHP], S4043
 4042 N
 4065 N
 D451 H 4051
 DNLM N [-TSJB], TSJC
 COUT N [-TSJC], TSJD
 4050 N
 U462 H 4062
 UPLM N [TYLM], TYLK
 COUT N [-TYLM], TYLN
 4071 N
 4073 N
 4062 N
 4072 N
 4079 N
 DNA1 C
 4089 N
 DNA1 C R4079AM. R4089AM. -4089
 4074 N
 DNAP N
 DNA1 C R4089AM
 TRAN DNA1
 D085 N
 4092 N 4091. -4092. -S4091. S4092
 TRAN N492
 4082 N

0244:		STEP. 08	
0245: 4094	D[D085]	4091 N	4092. -4091. -S4092. S4091
0246:	T	TRAN	0085
0247:			4092 N [TSKE], S4094. R4094AS
0248:			D085 N 4094. -D085. -S4094
0249: 4096	N, DU		
0250:	R	TRAN	
0251:			4092 N [TYJZ], S4096+LS4096(RR)I
0252:			
0253: 4145	N		
0254:			4151 N
[TNRD], R4145AM. (S4145+LS4145(RR)I)			
0255:	R	TRAI	
0256: 4151	N		4153 N
0257:			
[TSCE], R4151AM. (S4151+LS4151(RR)I)			
0258: 4152	N		A426 N
0259:			UGA1 C
[TYCP], R4152AM. (S4152+LS4152(RR)I)			4161 N
0260:			
0261: 4153	N		4152 N
0262:			UGA1 C -4152
[TSCH], R4153AM. (S4153+LS4153(RR)I)			4167 N
0263: 4158	N		
0264:			4158 N
[TYCK], R4158AM. (S4158+LS4158(RR)I)			
0265:			4175 N
0266: 4161	N		4177 N [TSAM], S4175+LS4175(RR)I
0267:			4181 N [S4181], P922N. 4176. -4181
[TSCM], R4161AM. (S4161+LS4161(RR)I)			4166 N
0268: 4166	N		
0269:			4185 N
[TYCD], R4166AM. (S4166+LS4166(RR)I)			4181 N
0270: 4167	N		
0271:			4176 N [TYAK], S4178
[TSCU], R4167AM. (S4167+LS4167(RR)I)			4176 N [TYAK], S4180
0272: 4175	N		4187 N
0273:			COUT N
0274: 4176	N		COUT N
0275:			4176 N [S4176], 4181. -4176
0276:			4189 N [TSAV], S4185+LS4185(RR)I
[TYCA], R4176AM. (S4176+LS4176(RR)I)			4176 N [TYAJ], S4186+LS4186(RR)I
0277: 4177	N		
0278:			4186 N [S4186], 4187
[TSAP], R4177A. (S4177+LS4177(RR)I)			4186 N [LS4186(RR)I], 4187
0279:			4191 N [TYAE], TYAH. S4187
[TSAP], R4177B. (S4177+LS4177(RR)I)			
0280: 4178	N		
0281:			
0282: 4180	N		
0283:			
0284: 4181	N		
0285:			
[TYAK], R4181AM. (S4181+LS4181(RR)I)			
0286:			
[TYAK], R4181BS. (S4181+LS4181(RR)I)			
0287:			
[TYAK], R4181CS. (S4181+LS4181(RR)I)			
0288:			
0289: 4185	N		
0290:			
0291: 4186	D[4187]		
0292:			
0293: 4187	D[4186]		
0294:			
0295:			
0296:			

STEP. 08

0297: 4188	D[4191]		
0298:			4186 N [TYAH], TYAE. S4188
0299:			4191 N [S4191], 4188
0300:			4191 N [LS4191(RR)I], 4188
0301: 4189	N		
0302:			4030 N [TSAY], S4189+LS4189(RR)I
0303:			ANUN C S4189+LS4189(RR)I
0304: 4190	N		
0305:			4188 N [TSAY], S4190
0306: 4191	D[4188]		
0307:			4030 N [TYAC], S4191+LS4191(RR)I
0308:			ANUN C S4191+LS4191(RR)I
0309: 4201	N		
0310:			4209 N
[TMBZ], R4201A.	(S4201+LS4201(RR)I)		
0311:			4217 N
[TMBZ], R4201B.	(S4201+LS4201(RR)I)		
0312:			4956 N [S4956], 4201. -4956
0313:			4956 N [LS4956(RR)I], 4201. -4956
0314:	T	TR05	
0315: 4202	D[4205]		
0316:			4205 N [S4205], 4202
0317:			4205 N [LS4205(RR)I], 4202
0318:			4961 N [TPZY], S4202+LS4202(RR)I
0319: 4203	D[4204]		
0320:			4204 N [S4204], 4203
0321:			4204 N [LS4204(RR)I], 4203
0322:			4209 N
[TMAD], R4203A.	(S4203+LS4203(RR)I)		
0323:			4217 N
[TMAD], R4203B.	(S4203+LS4203(RR)I)		
0324:	T	TR05	
0325: 4204	D[4203]		
0326:			4203 N [S4203], 4204
0327:			4203 N [LS4203(RR)I], 4204
0328:			4961 N
[TMAA], R4204A.	(S4204+LS4204(RR)I)		
0329:			4963 N
[TMAA], R4204B.	(S4204+LS4204(RR)I)		
0330: 4205	D[4202]		
0331:			4202 N [S4202], 4205
0332:			4202 N [LS4202(RR)I], 4205
0333:			4217 N [TPZU], S4205+LS4205(RR)I
0334:	T	TR05	
0335: 4208	N		
0336:			4202 N
[TPZS], R4208A.	(S4208+LS4208(RR)I)		
0337:			4204 N
[TPZS], R4208B.	(S4208+LS4208(RR)I)		
0338:			4956 N
[TPZS], R4208C.	(S4208+LS4208(RR)I)		
0339: 4209	D[4210]		
0340:			4210 N [S4210], 4209
0341:			4210 N [LS4210(RR)I], 4209
0342:			4211 N [TMAK], TMAJ. S4209
0343: 4210	D[4209]		
0344:			4204 N
[TMAG], R4210A.	(S4210+LS4210(RR)I)		
0345:			4956 N
[TMAG], R4210B.	(S4210+LS4210(RR)I)		
0346: 4211	N		
0347:			4241 N
[TMAN], R4211A.	(S4211+LS4211(RR)I)		
0348:			4219 N
[TMAN], R4211B.	(S4211+LS4211(RR)I)		
0349:			AMDM C R4211B. (S4211+LS4211(RR)I)
0350: 4212	D[4217]		
0351:			4208 N [TPZM], S4212+LS4212(RR)I

0352:		STEP. 08	4217 N [S4217], 4212
0353:			4217 N [LS4217(RR)I], 4212
0354: 4216	D[4219]		
0355:			4212 N [TMA5], S4216+LS4216(RR)I
0356: 4217	D[4212]		
0357:			4208 N [S4208], 4217. -4208
0358:			4208 N [LS4208(RR)I], 4217. -4208
0359:			4212 N [S4212], 4217
0360:			4212 N [LS4212(RR)I], 4217
0361:			4241 N
[TPZK], R4217A. (S4217+LS4217(RR)I)			
0362:			4219 N
[TPZK], R4217B. (S4217+LS4217(RR)I)			
0363: 4218	N		
0364:			4212 N [TPZG], S4218+LS4218(RR)I
0365: 4219	D[4216]		
0366:			4216 N [S4216], 4219
0367:			4216 N [LS4216(RR)I], 4219
0368:			4221 N [TMAW], TMAU. S4219
0369:	T	TR09	
0370: 4220	N		
0371:			4218 N [TPZF], TPZE. S4220
0372:	T	TR09	
0373: 4221	N		
0374:			4225 N [TMAX], TMAW. S4221
0375:	T	TR09	
0376: 4224	N		
0377:			4220 N [TPZE], TAA. S4224
0378:	T	TR09	
0379: 4225	N		
0380:			0803 N [TBA], TMAX. S4225
0381:	T	TR09	
0382: 4240	N		
0383:			4212 N [TPYH], (S4240+LS4240(RR)I)
0384: 4241	N		
0385:			4243 N [TMBD], TMBC. S4241
0386:			APDT C -4243. -4245
0387: 4242	N		
0388:			4240 N [TPYG], TPYE. S4242
0389: 4243	N		
0390:			4245 N [TMBE], TMBD. S4243
0391:			APDT C -4245
0392: 4244	N		
0393:			4242 N [TPYE], TPYD. S4244
0394: 4245	N		
0395:			4249 N [TMBG], TMBE. S4245
0396:			APDT C
0397: 4248	N		
0398:			4244 N [TPYD], TPYA. S4248
0399: 4249	N		
0400:			4633 N [TMBH], TMBG. S4249
0401:	T	TR05	
0402: 4250	N		
0403:			4248 N [TPYA], TRTZ. S4250
0404:	T	TR05	
0405: 4526	N		
0406:			UNLN H
0407:	T	TR05	
0408:	R	TR05	
0409: 4633	N		
0410:			DTLN H
0411:	T	TR05	
0412:	R	TR05	
0413: 4911	N		
0414:			4913 N [TNAJ], TNLX. S4911
0415:	T	TR05	
0416: 4912	N		
0417:			4526 N [TPLD], TPUV. S4912

0418:	T	STEP. 08
0419: 4913	N	TR05
0420:		4917 N [TNAK], TNAJ. S4913
0421:	T	TR05
0422: 4914	N	4912 N [TPUV], TPUT. S4914
0423:		TR05
0424:	T	COUT N
0425: 4917	N	COUT N
0426:		4925 N
[TNAM], R4917AS. (S4917+LS4917(RR)I)		4927 N
0427:		4931 N
[TNAM], R4917BS. (S4917+LS4917(RR)I)		4922 N
0428:		TR05
[TNAM], R4917CM. (S4917+LS4917(RR)I)		4914 N [TPUS], TPUR. S4918
0429:		4919 N [S4919], 4918
[TNAM], R4917DM. (S4917+LS4917(RR)I)		4919 N [LS4919(RR)I], 4918
0430:		TR05
[TNAM], R4917EM. (S4917+LS4917(RR)I)		COUT N
0431:		COUT N
[TNAM], R4917EC. (S4917+LS4917(RR)I)		4925 N
0432:	T	4927 N
0433: 4918	D[4919]	4931 N
0434:		4922 N
0435:		TR05
0436:		4914 N [TPUS], TPUR. S4918
0437:	T	4919 N [S4919], 4918
0438: 4919	D[4918]	4919 N [LS4919(RR)I], 4918
0439:		TR05
[TPUM], R4919AS. (S4919+LS4919(RR)I)		COUT N
0440:		COUT N
[TPUM], R4919BS. (S4919+LS4919(RR)I)		4925 N
0441:		4927 N
[TPUM], R4919CM. (S4919+LS4919(RR)I)		4931 N
0442:		4922 N
[TPUM], R4919DM. (S4919+LS4919(RR)I)		TR05
0443:		4918 N [TPTK], S4922+LS4922(RR)I
[TPUM], R4919EM. (S4919+LS4919(RR)I)		4931 N [R4917EC], 4922. -4931
0444:		4931 N [R4919EC], 4922. -4931
[TPUM], R4919EC. (S4919+LS4919(RR)I)		4931 N [S4931], 4922. -4931
0445:	T	4931 N [LS4931(RR)I], 4922. -4931
0446: 4922	N	ATUS C S4922+LS4922(RR)I
0447:		TR05
0448:		4918 N [TPUG], S4924+LS4924(RR)I
0449:		TR05
0450:		4935 N [TNBF], S4925+LS4925(RR)I
0451:		TR05
0452:		4918 N [TNBD], R4926AS. S4926
0453:	T	COUT N [TNBD], R4926BS. S4926
0454: 4924	N	ATDN C R4926AS. S4926
0455:		TR05
0456:	T	4937 N [TNAU], TNAT. S4927
0457: 4925	N	TR05
0458:		4918 N [TNBD], R4928AS. S4928
0459:	T	COUT N [TNBD], R4928BS. S4928
0460: 4926	N	ATDN C R4928AS. S4928
0461:		TR05
0462:		4918 N [TNBD], R4928AS. S4928
0463:		COUT N [TNBD], R4928BS. S4928
0464:	T	ATDN C R4928AS. S4928
0465: 4927	N	TR05
0466:		4918 N [TNBD], R4928AS. S4928
0467:	T	COUT N [TNBD], R4928BS. S4928
0468: 4928	N	ATDN C R4928AS. S4928
0469:		TR05
0470:		4918 N [TNBD], R4928AS. S4928
0471:		COUT N [TNBD], R4928BS. S4928
0472:	T	ATDN C R4928AS. S4928
0473: 4930	N	TR05

0474:
 0475:
 0476:
 0477:
 0478: T
 0479: 4931 N
 0480:
 [TPTG], R4931AM. (S4931+LS4931(RR)I)
 0481:
 [TPTG], R4931AC. (S4931+LS4931(RR)I)
 0482:
 [TPTG], R4931BS. (S4931+LS4931(RR)I)
 0483:
 0484:
 0485: T
 0486: 4934 N
 0487:
 0488: T
 0489: 4935 N
 0490:
 0491:
 0492:
 0493:
 0494: T
 0495: 4936 N
 0496:
 0497:
 0498:
 0499:
 0500: T
 0501: 4937 N
 0502:
 0503: T
 0504: 4938 N
 0505:
 0506: T
 0507: 4940 D[4947]
 0508:
 0509:
 0510:
 [TNBK], R4940AM. (S4940+LS4940(RR)I)
 0511:
 [TNBK], R4940AC. (S4940+LS4940(RR)I)
 0512: T
 0513: 4945 N
 0514:
 0515:
 0516:
 0517: T
 0518: 4946 D[4953]
 0519:
 0520:
 0521:
 0522: T
 0523: 4947 D[4940]
 0524:
 [TNBS], R4947A. (S4947+LS4947(RR)I)
 0525:
 0526:
 0527:
 [TNBS], R4947B. (S4947+LS4947(RR)I)
 0528: T
 0529: 4948 N
 0530:
 0531:
 0532: T
 0533: 4949 N
 0534:

STEP. 08

4918 N [TNBE], S4930+LS4930(RR)I
 4935 N [S4935], 4930. -4935
 4935 N [LS4935(RR)I], 4930. -4935
 ATDN C S4930+LS4930(RR)I
 TR05
 4945 N
 4936 N
 COUT N
 4922 N [S4922], 4931. -4922
 4922 N [LS4922(RR)I], 4931. -4922
 TR05
 4922 N [TPTG], S4934
 TR05
 4947 N [TNBK], S4935+LS4935(RR)I
 4930 N [S4930], 4935. -4930
 4930 N [LS4930(RR)I], 4935. -4930
 4930 N [R4940AC], 4935. -4930
 TR05
 4922 N [TPTG], S4936+LS4936(RR)I
 4945 N [S4945], 4936. -4945
 4945 N [LS4945(RR)I], 4936. -4945
 4945 N [R4931AC], 4936. -4945
 TR05
 4949 N [TNAV], TNAU. S4937
 TR05
 4924 N [TPUE], TPUD. S4938
 TR05
 4947 N [S4947], 4940
 4947 N [LS4947(RR)I], 4940
 4930 N
 4935 N
 TR05
 4953 N [TPTD], S4945+LS4945(RR)I
 4936 N [S4936], 4945. -4936
 4936 N [LS4936(RR)I], 4945. -4936
 TR05
 4953 N [S4953], 4946
 4953 N [LS4953(RR)I], 4946
 4936 N [TPTD], S4946+LS4946(RR)I
 TR05
 4201 N
 4940 N [S4940], 4947
 4940 N [LS4940(RR)I], 4947
 4955 N
 TR05
 4938 N [TPUD], TPUC. S4948
 ATUF C S4948
 TR05
 4957 N [TNAX], TNAV. S4949

0535:	T	STEP. 08
0536: 4952	N	TR05
0537:		
0538:	T	4948 N [TPUC], TPUB. S4952
0539: 4953	D[4946]	TR05
0540:		4946 N [S4946], 4953
0541:		4946 N [LS4946(RR)I], 4953
0542:		4961 N
[TPTB], R4953A. (S4953+LS4953(RR)I)		
0543:		4963 N
[TPTB], R4953B. (S4953+LS4953(RR)I)		
0544:		4965 N
[TPTB], R4953C. (S4953+LS4953(RR)I)		
0545:		4967 N
[TPTB], R4953D. (S4953+LS4953(RR)I)		
0546:	T	TR05
0547: 4954	N	
0548:		4940 N [TNBW], S4954+LS4954(RR)I
0549:		4955 N [S4955], 4954. -4955
0550:		4955 N [LS4955(RR)I], 4954. -4955
0551:	T	TR05
0552: 4955	N	
0553:		4961 N
[TNBY], R4955A. (S4955+LS4955(RR)I)		
0554:		4963 N
[TNBY], R4955B. (S4955+LS4955(RR)I)		
0555:		4954 N [S4954], 4955. -4954
0556:		4954 N [LS4954(RR)I], 4955. -4954
0557:	T	TR05
0558: 4956	N	
0559:		4940 N [TMBS], S4956+LS4956(RR)I
0560:		4201 N [S4201], 4956. -4201
0561:		4201 N [LS4201(RR)I], 4956. -4201
0562:	T	TR05
0563: 4957	N	
0564:		4961 N
[TNAY], R4957A. (S4957+LS4957(RR)I)		
0565:		4963 N
[TNAY], R4957B. (S4957+LS4957(RR)I)		
0566:		4965 N
[TNAY], R4957C. (S4957+LS4957(RR)I)		
0567:		4967 N
[TNAY], R4957D. (S4957+LS4957(RR)I)		
0568:	T	TR05
0569: 4960	N	
0570:		4946 N
[TPVS], R4960A. (S4960+LS4960(RR)I)		
0571:		4952 N
[TPVS], R4960B. (S4960+LS4960(RR)I)		
0572:		4967 N [S4967], 4960. -4967
0573:		4967 N [LS4967(RR)I], 4960. -4967
0574:	T	TR05
0575: 4961	N	
0576:		4001 N
[TNCG], R4961AM. (S4961+LS4961(RR)I)		
0577:		4981 N
[TNCG], R4961AC. (S4961+LS4961(RR)I)		
0578:		4003 N
[TNCG], R4961B1M. (S4961+LS4961(RR)I)		
0579:		4983 N
[TNCG], R4961B1C. (S4961+LS4961(RR)I)		
0580:		4966 N [S4966], 4961. -4966
0581:		4966 N [LS4966(RR)I], 4961. -4966
0582:		4969 N
[TNCG], R4961B2M. (S4961+LS4961(RR)I)		
0583:		4969 N
[TNCG], R4961B2C. (S4961+LS4961(RR)I)		
0584:		4969 N

[TNCG], R4961CM. (S4961+LS4961(RR)I)	STEP. 08
0585:	4969 N
[TNCG], R4961CC. (S4961+LS4961(RR)I)	
0586:	4969 N
[TNCG], R4961DM. (S4961+LS4961(RR)I)	
0587:	4969 N
[TNCG], R4961DC. (S4961+LS4961(RR)I)	
0588:	4969 N
[TNCG], R4961EM. (S4961+LS4961(RR)I)	
0589:	4969 N
[TNCG], R4961EC. (S4961+LS4961(RR)I)	
0590:	4969 N
[TNCG], R4961FM. (S4961+LS4961(RR)I)	
0591:	4969 N
[TNCG], R4961FC. (S4961+LS4961(RR)I)	
0592: 4962 N	
0593:	4946 N
[TPWS], R4962A. (S4962+LS4962(RR)I)	
0594:	4952 N
[TPWS], R4962B. (S4962+LS4962(RR)I)	
0595:	4965 N [S4965], 4962. -4965
0596:	4965 N [LS4965(RR)I], 4962. -4965
0597: T	TR05
0598: 4963 N	
0599:	4964 N [S4964], 4963. -4964
0600:	4964 N [LS4964(RR)I], 4963. -4964
0601:	4969 N [TNDK], S4963
0602:	4969 N [TNDK], LS4963(RR)I
0603: 4964 N	
0604:	4946 N
[TNDG], R4964A. (S4964+LS4964(RR)I)	
0605:	4952 N
[TNDG], R4964B. (S4964+LS4964(RR)I)	
0606:	4954 N
[TNDG], R4964C. (S4964+LS4964(RR)I)	
0607:	4203 N
[TNDG], R4964D. (S4964+LS4964(RR)I)	
0608:	4963 N [S4963], 4964. -4963
0609:	4963 N [LS4963(RR)I], 4964. -4963
0610:	4969 N [S4969], 4964. -4963. P880N
0611: T	TR05
0612: 4965 N	
0613:	4001 N
[TPWN], R4965AM. (S4965+LS4965(RR)I)	
0614:	4981 N
[TPWN], R4965AC. (S4965+LS4965(RR)I)	
0615:	4003 N [TPWN], (R4965B1M+
R4965B2M). (S4965+LS4965(RR)I)	
0616:	4983 N [TPWN], (R4965B1C+
R4965B2C). (S4965+LS4965(RR)I)	
0617:	4004 N
[TPWN], R4965CM. (S4965+LS4965(RR)I)	
0618:	4984 N
[TPWN], R4965CC. (S4965+LS4965(RR)I)	
0619:	4985 N
[TPWN], R4965DM. (S4965+LS4965(RR)I)	
0620:	4985 N
[TPWN], R4965DC. (S4965+LS4965(RR)I)	
0621:	4006 N
[TPWN], R4965EM. (S4965+LS4965(RR)I)	
0622:	4986 N
[TPWN], R4965EC. (S4965+LS4965(RR)I)	
0623:	4007 N
[TPWN], R4965FM. (S4965+LS4965(RR)I)	
0624:	4987 N
[TPWN], R4965FC. (S4965+LS4965(RR)I)	
0625:	4962 N [S4962], 4965. -4962
0626:	4962 N [LS4962(RR)I], 4965. -4962

STEP. 08

0627: 4966 N	
0628: [TNCE], R4966A. (S4966+LS4966(RR)I)	4946 N
0629: [TNCE], R4966B. (S4966+LS4966(RR)I)	4952 N
0630: [TNCE], R4966C. (S4966+LS4966(RR)I)	4954 N
0631: [TNCE], R4966D. (S4966+LS4966(RR)I)	4203 N
0632: [TNCE], R4966E. (S4966+LS4966(RR)I)	4205 N
0633:	4961 N [S4961], 4966. -4961
0634:	4961 N [LS4961(RR)I], 4966. -4961
0635:	4969 N [S4969], 4966. -4961. P880R
0636: T	TR05
0637: 4967 N	
0638: [TPVN], R4967AM. (S4967+LS4967(RR)I)	4001 N
0639: [TPVN], R4967AC. (S4967+LS4967(RR)I)	4981 N
0640: R4967B2M). (S4967+LS4967(RR)I)	4003 N [TPVN], (R4967B1M+
0641: R4967B2C). (S4967+LS4967(RR)I)	4983 N [TPVN], (R4967B1C+
0642: [TPVN], R4967CM. (S4967+LS4967(RR)I)	4004 N
0643: [TPVN], R4967CC. (S4967+LS4967(RR)I)	4984 N
0644: [TPVN], R4967DM. (S4967+LS4967(RR)I)	4985 N
0645: [TPVN], R4967DC. (S4967+LS4967(RR)I)	4985 N
0646: [TPVN], R4967EM. (S4967+LS4967(RR)I)	4006 N
0647: [TPVN], R4967EC. (S4967+LS4967(RR)I)	4986 N
0648: [TPVN], R4967FM. (S4967+LS4967(RR)I)	4007 N
0649: [TPVN], R4967FC. (S4967+LS4967(RR)I)	4987 N
0650:	4960 N [S4960], 4967. -4960
0651:	4960 N [LS4960(RR)I], 4967. -4960
0652: 4969 N	
0653: [TNDM], (R4969APSM+R4969ASNP). S4969	4001 N
0654: [TNDM], (R4969APSC+R4969ASP). S4969	4981 N
0655: [TNDM], (R4969B1PSM+R4969B1SNP). S4969	4003 N
0656: [TNDM], (R4969B1PSC+R4969B1SP). S4969	4983 N
0657: [TNDM], (R4969B2PSM+R4969B2SNP). S4969	4003 N
0658: [TNDM], (R4969B2PSC+R4969B2SP). S4969	4983 N
0659: [TNDM], (R4969CPSM+R4969CSNP). S4969	4004 N
0660: [TNDM], (R4969CPSC+R4969CSP). S4969	4984 N
0661: [TNDM], (R4969DPSM+R4969DSNP). S4969	4985 N
0662: [TNDM], (R4969DPSC+R4969DSP). S4969	4985 N
0663: [TNDM], (R4969EPSM+R4969ESNP). S4969	4006 N
0664: [TNDM], (R4969EPSC+R4969ESP). S4969	4986 N
0665:	4007 N

STEP. 08

[TNDM], (R4969FPSM+R4969FSNP). S4969
 0666: 4987 N
 [TNDM], (R4969FPSC+R4969FSP). S4969
 0667: 4981 N
 0668: 4001 N [S4001], 4981. -PLT1. -4001
 0669: 4001 N [LS4001(RR)I], 4981. -PLT1. -4001
 0670: 4960 N
 [TRAB], R4981A. (S4981+LS4981(RR)I)
 0671: 4962 N
 [TRAB], R4981B. (S4981+LS4981(RR)I)
 0672: 4964 N
 [TRAB], R4981C. (S4981+LS4981(RR)I)
 0673: 4966 N
 [TRAB], R4981D. (S4981+LS4981(RR)I)
 0674: COUT N [-TRAC], -TRAD. -TRAE. 4981
 0675: COUT N [-TRAE], -TRAC. -TRAD. 4981
 0676: PLT1 N [R4961AC], 4981. -PLT1
 0677: PLT1 N [R4965AC], 4981. -PLT1
 0678: PLT1 N [R4967AC], 4981. -PLT1
 0679: PLT1 N [R4969APSC], 4981. -PLT1
 0680: PLT1 N [R4969ASP], 4981. -PLT1
 0681: PLT1 N [-PLT1], R4961AC. 4981
 0682: PLT1 N [-PLT1], R4965AC. 4981
 0683: PLT1 N [-PLT1], R4967AC. 4981
 0684: PLT1 N [-PLT1], R4969APSC. 4981
 0685: PLT1 N [-PLT1], R4969ASP. 4981
 0686: 4983 N
 0687: 4003 N [S4003], 4983. -PLT3. -4003
 0688: 4003 N [LS4003(RR)I], 4983. -PLT3. -4003
 0689: 4960 N
 [TNCS], (R4983A1M+R4983A2M). (S4983+LS4983(RR)I)
 0690: 4962 N
 [TNCS], (R4983B1M+R4983B2M). (S4983+LS4983(RR)I)
 0691: 4964 N
 [TNCS], (R4983C1M+R4983C2M). (S4983+LS4983(RR)I)
 0692: 4966 N
 [TNCS], (R4983D1M+R4983D2M). (S4983+LS4983(RR)I)
 0693: COUT N [-TNCT], -TNCU. -TNCV. 4983
 0694: COUT N [-TNCV], -TNCT. -TNCU. 4983
 0695: PLT3 N [R4961B1C], 4983. -PLT3
 0696: PLT3 N [R4965B1C], 4983. -PLT3
 0697: PLT3 N [R4965B2C], 4983. -PLT3
 0698: PLT3 N [R4967B1C], 4983. -PLT3
 0699: PLT3 N [R4967B2C], 4983. -PLT3
 0700: PLT3 N [R4969B1SP], 4983. -PLT3
 0701: PLT3 N [R4969B2SP], 4983. -PLT3
 0702: PLT3 N [R4969B1PSC], 4983. -PLT3
 0703: PLT3 N [R4969B2PSC], 4983. -PLT3
 0704: PLT3 N [-PLT3], R4961B1C. 4983
 0705: PLT3 N [-PLT3], R4965B1C. 4983
 0706: PLT3 N [-PLT3], R4965B2C. 4983
 0707: PLT3 N [-PLT3], R4967B1C. 4983
 0708: PLT3 N [-PLT3], R4967B2C. 4983
 0709: PLT3 N [-PLT3], R4969B1SP. 4983
 0710: PLT3 N [-PLT3], R4969B2SP. 4983
 0711: PLT3 N [-PLT3], R4969B1PSC. 4983
 0712: PLT3 N [-PLT3], R4969B2PSC. 4983
 0713: 4984 N
 0714: 4960 N
 [TNDU], R4984A. (S4984+LS4984(RR)I)
 0715: 4962 N
 [TNDU], R4984B. (S4984+LS4984(RR)I)
 0716: 4964 N
 [TNDU], R4984C. (S4984+LS4984(RR)I)
 0717: 4966 N
 [TNDU], R4984D. (S4984+LS4984(RR)I)
 0718: 4004 N [S4004], 4984. -4004
 0719: 4004 N [LS4004(RR)I], 4984. -4004

STEP. 08

0720:	4004 N [R4965CC], 4984. -4004
0721:	4004 N [R4967CC], 4984. -4004
0722:	4004 N [R4969CPSC], 4984. -4004
0723:	4004 N [R4969CSP], 4984. -4004
0724:	COUT N [-TNDW], -TNDX. 4984
0725:	COUT N [-TNDX], -TNDW. 4984
0726: 4985 N	
0727:	4960 N
[TNDT], R4985A. (S4985+LS4985(RR)I)	
0728:	4962 N
[TNDT], R4985B. (S4985+LS4985(RR)I)	
0729:	4964 N
[TNDT], R4985C. (S4985+LS4985(RR)I)	
0730:	4966 N
[TNDT], R4985D. (S4985+LS4985(RR)I)	
0731:	COUT N [-TRBC], -TRBD. 4985
0732:	PLT5 N [R4965DC], 4985. -PLT5
0733:	PLT5 N [-PLT5], 4985. R4965DC
0734:	PLT5 N [R4967DC], 4985. -PLT5
0735:	PLT5 N [-PLT5], 4985. R4967DC
0736:	PLT5 N [R4969DSP], 4985. -PLT5
0737:	PLT5 N [-PLT5], 4985. R4969DSP
0738:	PLT5 N [R4969DPSC], 4985. -PLT5
0739:	PLT5 N [-PLT5], 4985. R4969DPSC
0740: 4986 N	
0741:	4006 N [S4006], 4986. -PLT6. -4006
0742:	4006 N [LS4006(RR)I], 4986. -PLT6. -4006
0743:	4960 N
[TPWG], R4986A. (S4986+LS4986(RR)I)	
0744:	4962 N
[TPWG], R4986B. (S4986+LS4986(RR)I)	
0745:	4964 N
[TPWG], R4986C. (S4986+LS4986(RR)I)	
0746:	4966 N
[TPWG], R4986D. (S4986+LS4986(RR)I)	
0747:	COUT N [-TPWD], -TPWE. -TPWF. 4986
0748:	COUT N [-TPWF], -TPWD. -TPWE. 4986
0749:	PLT6 N [R4965EC], 4986. -PLT6
0750:	PLT6 N [R4967EC], 4986. -PLT6
0751:	PLT6 N [R4969ESP], 4986. -PLT6
0752:	PLT6 N [R4969EPSC], 4986. -PLT6
0753:	PLT6 N [-PLT6], R4965EC. 4986
0754:	PLT6 N [-PLT6], R4967EC. 4986
0755:	PLT6 N [-PLT6], R4969ESP. 4986
0756:	PLT6 N [-PLT6], R4969EPSC. 4986
0757: 4987 N	
0758:	4007 N [S4007], 4987. -PLT7. -4007
0759:	4007 N [LS4007(RR)I], 4987. -PLT7. -4007
0760:	4960 N
[TPVH], R4987A. (S4987+LS4987(RR)I)	
0761:	4962 N
[TPVH], R4987B. (S4987+LS4987(RR)I)	
0762:	4964 N
[TPVH], R4987C. (S4987+LS4987(RR)I)	
0763:	4966 N
[TPVH], R4987D. (S4987+LS4987(RR)I)	
0764:	COUT N [-TPVE], -TPVF. -TPVG. 4987
0765:	COUT N [-TPVG], -TPVE. -TPVF. 4987
0766:	PLT7 N [R4965FC], 4987. -PLT7
0767:	PLT7 N [R4967FC], 4987. -PLT7
0768:	PLT7 N [R4969FPSC], 4987. -PLT7
0769:	PLT7 N [R4969FSP], 4987. -PLT7
0770:	PLT7 N [-PLT7], R4965FC. 4987
0771:	PLT7 N [-PLT7], R4967FC. 4987
0772:	PLT7 N [-PLT7], R4969FPSC. 4987
0773:	PLT7 N [-PLT7], R4969FSP. 4987
0774: R002 N	
0775:	4002 N

STEP. 08

[-4002], R002. (S4002+LS4002(RR)I)	
0776: R985 N	
0777:	PLT5 N
[-PLT5], R985. (S4985+LS4985(RR)I)	
0778:	PLT5 N
[-4985], -PLT5. R985. (S4985+LS4985(RR)I)	
0779: PLT1 N	
0780:	4001 N [LS4001(RR)I], PLT1. -4001
0781:	4001 N [S4001], PLT1. -4001
0782:	4001 N [R4961AC], PLT1. -4001
0783:	4001 N [R4965AC], PLT1. -4001
0784:	4001 N [R4967AC], PLT1. -4001
0785:	4001 N [R4969APSC], PLT1. -4001
0786:	4001 N [R4969ASP], PLT1. -4001
0787:	4981 N [LS4981(RR)I], PLT1. -4981
0788:	4981 N [S4981], PLT1. -4981
0789:	4981 N [R4014GSP], PLT1. -4981
0790:	4981 N [R4016FC], PLT1. -4981
0791:	4981 N [R4020FC], PLT1. -4981
0792:	4981 N [R4022FC], PLT1. -4981
0793:	COUT N [-TRAC], -TRAD. -TRAE. PLT1
0794:	COUT N [-TRAE], -TRAC. -TRAD. PLT1
0795: PLT3 N	
0796:	4003 N [LS4003(RR)I], PLT3. -4003
0797:	4003 N [S4003], PLT3. -4003
0798:	4003 N [R4961B1C], PLT3. -4003
0799:	4003 N [R4965B1C], PLT3. -4003
0800:	4003 N [R4965B2C], PLT3. -4003
0801:	4003 N [R4967B1C], PLT3. -4003
0802:	4003 N [R4967B2C], PLT3. -4003
0803:	4003 N [R4969B1SP], PLT3. -4003
0804:	4003 N [R4969B2SP], PLT3. -4003
0805:	4003 N [R4969B1PSC], PLT3. -4003
0806:	4003 N [R4969B2PSC], PLT3. -4003
0807:	4983 N [LS4983(RR)I], PLT3. -4983
0808:	4983 N [S4983], PLT3. -4983
0809:	4983 N [R4014ESP], PLT3. -4983
0810:	4983 N [R4016DC], PLT3. -4983
0811:	4983 N [R4020DC], PLT3. -4983
0812:	4983 N [R4022DC], PLT3. -4983
0813:	COUT N [-TNCT], -TNCU. -TNCV. PLT3
0814:	COUT N [-TNCV], -TNCT. -TNCU. PLT3
0815: PLT5 N	
0816:	4985 N
[-4985], PLT5. (S4985+LS4985(RR)I)	
0817:	4985 N
[PLT5], -4985. (S4985+LS4985(RR)I)	
0818:	R985 N [R4965DC], 4985. PLT5. -R985
0819:	R985 N [R4967DC], 4985. PLT5. -R985
0820:	R985 N [R4969DSP], 4985. PLT5. -R985
0821:	R985 N [R4969DPSC], 4985. PLT5. -R985
0822: PLT6 N	
0823:	4006 N [LS4006(RR)I], PLT6. -4006
0824:	4006 N [S4006], PLT6. -4006
0825:	4006 N [R4965EC], PLT6. -4006
0826:	4006 N [R4967EC], PLT6. -4006
0827:	4006 N [R4969ESP], PLT6. -4006
0828:	4006 N [R4969EPSC], PLT6. -4006
0829:	4986 N [LS4986(RR)I], PLT6. -4986
0830:	4986 N [S4986], PLT6. -4986
0831:	4986 N [R4012CSP], PLT6. -4986
0832:	4986 N [R4014CSP], PLT6. -4986
0833:	4986 N [R4016BC], PLT6. -4986
0834:	4986 N [R4020BC], PLT6. -4986
0835:	4986 N [R4022BC], PLT6. -4986
0836:	COUT N [-TPWD], -TPWE. -TPWF. PLT6
0837:	COUT N [-TPWF], -TPWD. -TPWE. PLT6
0838: PLT7 N	

STEP. 08

0839:		4007 N [LS4007(RR)I], PLT7. -4007
0840:		4007 N [S4007], PLT7. -4007
0841:		4007 N [R4965FC], PLT7. -4007
0842:		4007 N [R4967FC], PLT7. -4007
0843:		4007 N [R4969FPSC], PLT7. -4007
0844:		4007 N [R4969FSP], PLT7. -4007
0845:		4987 N [LS4987(RR)I], PLT7. -4987
0846:		4987 N [S4987], PLT7. -4987
0847:		4987 N [R4012BSP], PLT7. -4987
0848:		4987 N [R4014BSP], PLT7. -4987
0849:		4987 N [R4016AC], PLT7. -4987
0850:		4987 N [R4020AC], PLT7. -4987
0851:		4987 N [R4022AC], PLT7. -4987
0852:		COUT N [-TPVE], -TPVF. -TPVG. PLT7
0853:		COUT N [-TPVG], -TPVE. -TPVF. PLT7
*		
* DUMY BERTHS		
*		
0854: DUMY	N, BJKV	
0855:		COUT N [DUMY]
0856: DY05	N, BJKV	
0857:	T	TR05 DUMY
0858:		COUT N [DY05]
0859: DY09	N, BJKV	
0860:	T	TR09 DUMY
0861:		COUT N [DY09]
*		
* CROSS WORKSTATION BOUNDARY		
*		
0862: ANUN	N, DJKU	
0863:		DUMY N [TYHZ], S4034+LS4034(RR)I
0864:		DUMY N [TSAY], S4189+LS4189(RR)I
0865:		DUMY N [TYAC], S4191+LS4191(RR)I
0866: AEDN	N, DJKU	
0867:		DUMY N
[TRAG], R4001BM. (S4001+LS4001(RR)I)		
0868:		DUMY N
[TRAG], R4002BM. (S4002+LS4002(RR)I)		
0869:		DUMY N
[TNCW], R4003BM. (S4003+LS4003(RR)I)		
0870:		DUMY N
[TNDY], R4004BM. (S4004+LS4004(RR)I)		
0871:		DUMY N
[TPWB], R4006BM. (S4006+LS4006(RR)I)		
0872:		DUMY N
[TPVD], R4007BM. (S4007+LS4007(RR)I)		
0873: DNLN	N, BJKV	
0874:		LNDN N [TNEJ], TNEF. S4019
0875: LEUN	N, JK	
0876: LNDN	N, JK	
0877: UNLE	N, BJKV	
0878:		LEUN N [TPXU], (S4016+LS4016(RR)I)
*		
* 05 TD EREWASH WESTCAD		
*		
0879: 4634	N, JKV	
0880:	R	TR05
0881: 4636	N, JKV	
0882:	R	TR05
0883: 4638	N, JKV	
0884:	R	TR05
0885: ANUT	N, DJKU	
0886:	R	TR05
0887: APDT	N, BJKV	
0888:		DY05 N [TMBG], TMBE. S4245
0889:	T	TR05
0890: DTLN	N, BJKV	
0891:		LNDT N [-4633]

STEP. 08

0892: LNDT N, JK

*

* 05 TD TRENT WESTCAD

*

0893: 4523 N

0894: R

TR05

0895: 4525 N

0896: R

TR05

0897: ATDN N, BJKV

0898:

DY05 N [TNBD], S4926. R4926AS

0899:

DY05 N [TNBD], S4928. R4928AS

0900:

DY05 N [TNBE], S4930+LS4930(RR)I

0901: T

TR05

0902: ATUF N, BJKV

0903:

DY05 N [TPUD], TPUC. S4948

0904: T

TR05

0905: ATUS N, BJKV

0906:

DY05 N [TPTK], S4922+LS4922(RR)I

0907: T

TR05

0908: ANDN N, DJKU

0909: R

TR05

0910: LNUN N, JK

0911: UNLN N, BJKV

0912:

LNUN N [-4526]

*

*BERTHS REQUIRED FOR ARS

*

0913: 4421 N, BJKPV

0914: R

TR05

0915: 4424 N, BJKPV

0916: R

TR05

0917: 4426 N, BJKPV

0918: R

TR05

0919: 4428 N, BJKPV

0920: R

TR05

0921: 4430 N, BJKPV

0922: R

TR05

0923: 4442 N, BJKPV

0924: R

TR05

0925: 4444 N, BJKPV

0926: R

TR05

0927: 4493 N, BJKPV

0928: R

TR05

0929: 4495 N, BJKPV

0930: R

TR05

0931: 4497 N, BJKPV

0932: R

TR05

0933: 4499 N, BJKPV

0934: R

TR05

0935: 4501 N, BJKPV

0936: R

TR05

0937: 4502 N, BJKPV

0938: R

TR05

0939: 4503 N, BJKPV

0940: R

TR05

0941: 4505 N, BJKPV

0942: R

TR05

0943: 4507 N, BJKPV

0944: R

TR05

0945: 4511 N, BJKPV

0946: R

TR05

0947: 4512 N, BJKPV

0948: R

TR05

0949: 4513 N, BJKPV

0950: R

TR05

0951: 4515 N, BJKPV

0952: R

TR05

0953: 4517 N, BJKPV

STEP. 08

0954:	R	TR05
0955: 4519	N, BJKPV	
0956:	R	TR05
0957: 4521	N, BJKPV	
0958:	R	TR05
0959: 4522	N, BJKPV	
0960:	R	TR05
0961: 4529	N, BJKPV	
0962:	R	TR05
0963: 4531	N, BJKPV	
0964:	R	TR05
0965: 4532	N, BJKPV	
0966:	R	TR05
0967: 4533	N, BJKPV	
0968:	R	TR05
0969: 4535	N, BJKPV	
0970:	R	TR05
0971: 4537	N, BJKPV	
0972:	R	TR05
0973: 4541	N, BJKPV	
0974:	R	TR05
0975: 4543	N, BJKPV	
0976:	R	TR05
0977: 4545	N, BJKPV	
0978:	R	TR05
0979: 4555	N, BJKPV	
0980:	R	TR05
0981: 4557	N, BJKPV	
0982:	R	TR05
0983: 4558	N, BJKPV	
0984:	R	TR05
0985: 4560	N, BJKPV	
0986:	R	TR05
0987: 4568	N, BJKPV	
0988:	R	TR05
0989: 4572	N, BJKPV	
0990:	R	TR05
0991: 4576	N, BJKPV	
0992:	R	TR05
0993: 4584	N, BJKPV	
0994:	R	TR05
0995: 4586	N, BJKPV	
0996:	R	TR05
0997: 4588	N, BJKPV	
0998:	R	TR05
0999: 4592	N, BJKPV	
1000:	R	TR05
1001: 4594	N, BJKPV	
1002:	R	TR05
1003: 4598	N, BJKPV	
1004:	R	TR05

*

* 09 TD MANSFIELD WESTCAD

*

1005: 0800	N	
1006:	R	TR09
1007: 0803	N	
1008:		DMLN H
1009:	T	TR09
1010:	R	TR09
1011: 0804	N, JKV	
1012:	R	TR09
1013: AMDM	N, BJKV	
1014:		DY09 N
[TMAN], R4211B. (S4211+LS4211(RR)I)		
1015:	T	TR09
1016: ANUM	N, DJKU	
1017:	R	TR09

STEP. 08

1018: DMLN N, BJKV

1019:

1020: LNDM N, JK

*

* ALLINGTON TD

*

1021: A426 N, JK

1022: T

1023:

1024:

1025: UGA1 N, JKV

1026: T

1027: ALLS N, JK

1028: DGA1 N, DJK

1029: R

*

* DONCASTER TD

*

1030: DNAP N

1031: T

1032:

1033:

1034: D085 D[4094], JK

1035: T

1036:

1037:

1038: DCLS N, JK

1039: DNA1 N, JKV

1040: T

1041: UNA1 N, DJK

1042: R

*

* ALARM BERTHS

*

1043: UDLL A, JK

1044: RADL A, JK

1045: SLK1 A, JK

1046: TLK1 A, JK

1047: SLK2 A, JK

1048: TLK2 A, JK

1049: TRT1 A, JK

1050: TRT2 A, JK

1051: TRAI A, JK

1052: TRAN A, JK

1053: TR05 A, JK

1054: TR09 A, JK

*

* TD SUPPORT BERTHS

*

1055: CLCK C

1056:

1057: DATE F

1058:

1059: YEAR G

1060:

1061: STIN Y

1062:

1063:

1064:

1065: COUT Z

1066:

1067:

1068:

*

* NONE DESCRIBED ALARM BERTHS

*

1069: NDSD N, BJKPV

1070:

LNDM N [-0803]

TRAI 3426

ALLS H

COUT N [-TNUS/NUR]

TRAI

TRAI

TRAN DNA1

D085 N [TSKE], R4089AM

DNA1 C R4089AM

TRAN 0085

DCLS N [-T1741], T1742. D085

4094 N D085. -4094. S4094. R4094AS

TRAN

TRAN

TR05

TR09

TRAI

TRAN

TR05

TR09

TRAI

TRAN

4012 N [R4012BSNP], -4012

STEP. 08

1071:	4012 N [R4012BSP], -4012
1072:	4012 N [R4012CSNP], -4012
1073:	4012 N [R4012CSP], -4012
1074:	4012 N [R4012DSNP], -4012
1075:	4012 N [R4012DSP], -4012
1076:	4014 N [R4014BSNP], -4014
1077:	4014 N [R4014BSP], -4014
1078:	4014 N [R4014CSNP], -4014
1079:	4014 N [R4014CSP], -4014
1080:	4014 N [R4014DSNP], -4014
1081:	4014 N [R4014DSP], -4014
1082:	4014 N [R4014ESNP], -4014
1083:	4014 N [R4014ESP], -4014
1084:	4014 N [R4014FSNP], -4014
1085:	4014 N [R4014FSP], -4014
1086:	4014 N [R4014GSNP], -4014
1087:	4014 N [R4014GSP], -4014
1088:	4178 N [R4178], -4178
1089:	4180 N [R4180], -4180
1090:	4926 N [R4926AS], -4926
1091:	4928 N [R4928AS], -4928
1092:	4934 N [R4934], -4934

*

PRODUCED_____ SI GNATURE_____ DATE_____

*

*

CHECKED_____ SI GNATURE_____ DATE_____

*

*HI STORY:

*07/08/12	v1.0 INITIAL DESIGN FOR EMCC SYSTEM 08 TD
*15/04/13	v1.1 UPDATES TO TEST LOG
*13/06/13	v1.2 UPDATES TO ADDRESS FAT 1 TEST LOGS
*19/08/13	v1.3 UPDATES TO ADDRESS TEST LOG
*25/08/13	v1.4 UPDATES TO COMMISSIONING TEST LOG
*10/09/13	v1.5 UPDATES TO DRACAS OBSERVATION FORM & ADDRESS ARS ISSUES
*11/09/15	v2.0 EAST NOTTS WESTCAD
*02/11/15	v2.1 EAST NOTTS WESTCAD TESTING COMMENTS UPDATES
*09/12/15	v2.2 EAST NOTTS POST COMM STEP MOD
*10/05/16	v3.0 EAST NOTTS NOB STAGE
*09/06/16	V3.1 UPDATE FOR ACI AND SMART COMMENTS
